



Instructions for the Tiny Iron-on Tags

The tiny (7/8" x 1/4") tags come on a paper backing and are applied with a very hot iron (350 degrees or more). They are designed for very small items or garments where the tags cannot be showing. These tags can be applied the same as the regular iron-on material but particular attention needs to placed to the surface you use for the ironing.

> 1) Pre-heat your Petite Press to setting #4. Wait for the thermostat light to stop flashing.

2) Use a firm base for the ironing. Many ironing boards are too soft and the iron can't connect to the tag well and heat the adhesive. I have used a piece of very heavy cardboard or masonite with a piece of fabric on it. You can get 'ironing board fabric' at the fabric store and use it to cover the wood/cardboard.

Make a cover from ironing board fabric for the cardboard or masonite.

3) Place the tag on the garment and press with the Petite Press for 6-8 seconds. If you have enough heat and pressure you will see a little of the glue seep out around the edge of the tag - but just a tiny amount. The Petite Press will cover the tag completely. If you leave the iron on too long it will melt the adhesive too much and the tag won't stick.

4) Let the tag cool completely before washing or dry cleaning.









Inventory Resources



www.CostumeInventory.com